Smartphones & Tablets | Windows[™] How can I reset my Cesium tablet ?



We recommend to use this procedure for all the locked devices that can't be unlocked, all the devices that do not boot and all the devices that encounter a software malfunctioning. You will restore the device to its default settings and erase the internal storage. Before restoring the device, save your data and charge fully the device's battery.

Caution: if you reset your tablet without activating the Office license, you will lose the free license that was included with your device. You will need then to purchase a new license to use Office. So make sure to activate the provided license before you start resetting the device.

1. If you can't access the Windows® interface

- a. Press the ON/OFF button to turn on your device.
- b. If you have locked your device with a password, type in the password to unlock.
- c. On the tablet's homescreen, slide your finger to the left from the right edge of the screen.
- d. Select "Settings", then "Modify the PC settings".

Smartphones & Tablets | Windows™



e. In the "PC settings" page, select "Update & recovery", then select



 If your device doesn't function properly, you can update it without erasing your photos, your music, your vids or other personal files: Select "Start" to update your tablet without damaging your files.

 Update and rec Windows Update File History 	Refresh your PC without affecting your files If your PC isn't running well, you can refresh it without losing your photos, music, videos, and other personal files. Get started
Recovery	Remove everything and reinstall Windows
	If you want to recycle your PC or start over completely, you can reset it to its factory settings. Get started
	Advanced startup
	Start up from a device or disc (such as a USB drive or DVD), change your PC's firmware settings, change Windows startup settings, or restore Windows from a system image. This will restart your PC. Restart now

• If you want to clean up totally your tablet or refurbish it, you can restore it to its default settings: Select "Start" to delete

Page 2 / 4

(c) 2024 ARCHOS <noreply@archos.com> | 2024-04-26 23:02

URL: http://faq.archos.com//index.php?action=artikel&cat=1&id=383&artlang=en

Smartphones & Tablets | Windows™

Windows and reinstall it.



2. If you can't access the Windows® interface

This procedure will remove all your data, and also the free Office 365 license

- a. Turn off your tablet by holding the ON/OFF button Wait 30 seconds until the device is completely turned off.
- b. Hold the Volume and press the ON/OFF button to restart the device.
- c. Release the volume button only when the charging process is shown



- d. Connect the USB charger to your tablet.
- e. Once the recover interface is displayed, select **Troubleshoot**, then **Reset your PC** on the touch panel.

Reset your r e on the totten punch.		
Choose an option	Reset your PC If you want to remove all of your files, you can reset your PC completely.	
Exit and continue to Windows 8	Advanced options	
Troubleshoot Refresh or reset your PC, or use advanced tools		
Turn off your PC		

f. Validate then select **Just remove my files** in the last displayed screen.

Page 3 / 4 (c) 2024 ARCHOS <noreply@archos.com> | 2024-04-26 23:02 URL: http://faq.archos.com//index.php?action=artikel&cat=1&id=383&artlang=en

Smartphones & Tablets | Windows™

Unique solution ID: #1736 Author: Admin FAQ Last update: 2022-09-05 08:44

> Page 4 / 4 (c) 2024 ARCHOS <noreply@archos.com> | 2024-04-26 23:02 URL: http://faq.archos.com//index.php?action=artikel&cat=1&id=383&artlang=en