
Motion Ball

How I can change the Motion Ball batteries ?

The Motion Ball functions with 3 Lithium CR2450 / 3V batteries.

To change the batteries, unscrew the Motion Ball counter-clockwise. Insert the batteries with the - side facing the connectors. Screw back up.



Unique solution ID: #1644
Author: Admin FAQ
Last update: 2014-11-18 09:58

(c) 2024 ARCHOS <noreply@archos.com> | 2024-03-28 15:31
URL: http://faq.archos.com//index.php?action=artikel&cat=122&id=256&artlang=en