

My ARCHOS Hello

What are the different meanings of the LED?

- Red light: Mic deactivated
- No light: Mic activated
- Yellow light: Low battery

Unique solution ID: #2071

Author: Djibril

Last update: 2018-10-11 17:15