

Weather Tag

How can I change the batteries of my Weather Tag ?

The Weather Tag requires a Lithium CR2430 / 3V battery to operate and take measures.

To change the battery, you can remove the rubber case and the top of Weather Tag. Make sure you insert the batteries in the same orientation, the bottom of the battery (-) being the contact zone with the connectors.



Unique solution ID: #1610

Author: Admin FAQ

Last update: 2014-11-18 09:57