


# Battery & Display

## How can I calibrate my touchscreen?

Touchscreen calibration is carried out automatically when the device starts. For early models, you can do it manually.

To do screen calibration manually, go to **Settings**  (or ) >  **Repairing & formatting**

If this option is not available, launch the startup wizard in the **Settings** > **About the device**  . Press Start wizard restart the device.

It is important not to touch the screen of your device whilst the touchscreen calibration is working.

Unique solution ID: #1528

Author: Admin FAQ

Last update: 2014-11-14 16:27