

Ethereum

Receive Ethers

We consider in the following “How to” that your device is already configured. If it's not, please check our video on our website: “Configure your Safe-T mini”.

To send and receive Ethers, please connect to: safe-t.io.

Ethereum

MyCrypto English Ethereum (AUTC)

View & Send Create New Wallet Swap Contracts ENS Sign & Verify Message TX Status Broadcast Transaction Help of

Send Ether & Tokens Request Payment Wallet Info Recent Transactions Address Book Change Wallet

To Address
0x1E410FF800589186bC2f830619f063E4AD78D69f

Amount
1 Select...

Automatically Calculate Gas Limit
Gas Limit
21000

Account Address
0x1E410FF800589186bC2f830619f063E4AD78D69f
[copy address](#) [add label](#)
[Display address on Safe-T mini](#)

Account Balance
0 ETH

Transaction History
[Ethereum \(https://etherscan.io\)](#)
[Ethereum \(https://www.etherchain.org\)](#)
[Tokens \(https://ethplorer.io\)](#)

Buy now (asset) to generate ETH
Buy ETH with USD [coinbase](#)

Token Balances
[Scan For Tokens](#)

Ethereum

Your receiving address is now displayed in the “To Address” box and on the right of the screen.

This is the address on which people have to send ethers in order for you to receive them.

Gas are the fees to validate the ethers transaction. We recommend not to change the Gas limit displayed.

For security reason, will also recommend you to click on “Display address on Safe-T mini” section. This will display on your Safe-T mini your receiving address and your QR code, and you can check those are the same than on your computer screen.

Indeed, your computer screen could be hacked while what’s displayed on your Safe-T mini is cannot.

Unique solution ID: #2090

Author: Djibril

Last update: 2018-11-22 11:06