


Connecting a peripheral

How can I remove my micro-SD card correctly?

It is very important to remove your micro-SD card correctly if you want to avoid losing its contents. There are two methods:

- from the notifications bar, simply press the message related to the inserted card.

- In  (or ) **Settings** >  **Storage** > Uninstall SD card.

 Please note that the applications installed in your micro-SD card won't work anymore if you remove the card from your device.

Unique solution ID: #1567

Author: Admin FAQ

Last update: 2014-11-14 16:50