

Xenon Series

How to reinitialize my ARCHOS 50 Platinum ?



This process is recommended for your device if : it is frozen, it doesn't turn on or you are experiencing a software issue. It will allow you to perform a low level format on your device. Thus all the data will be deleted, you won't be able to retrieve them. We strongly recommend to back them up first. Keep in mind that your device's battery must be charged enough to perform this operation.

1. If you can have access to the Android™ interface
 - a. Select the Settings app then select Backup & reset > Factory data reset
 - b. To delete music, photos and other user data, you must erase the internal SD card. Tick "Erase phone storage"
 - c. Select "Reset phone" and confirm
2. If you can't access the Android™ interface
 - a. Turn off the device by using ON/OFF (remove then replace the battery if necessary)
 - b. Press simultaneously Volume + and the ON/OFF button, a green screen is displayed
 - c. Hold Volume + and release the ON/OFF button, a red screen is displayed
 - d. Release Volume +

Use the volume buttons to scroll down and up and the ON/OFF button to validate.

Xenon Series



If you failed to access to the recovery menu, please start again from the beginning.

- a. Select "Wipe data/factory reset" and validate to restore your device to its default settings
- b. Select "Yes -- delete all user data" and validate to remove all the user data
- c. Select "Reboot system now" and validate to reboot the device

Unique solution ID: #1127

Author: Admin FAQ

Last update: 2014-06-27 12:00