

Music Beany

How can I charge the Music Beany?

To charge the Music Beany, plug in a USB cable into the charging hole on the controller side of the beany. The other end of the USB cable should be plugged into a computer port or a compatible wall charger.

The Music Beany takes 2h 30 min for a full charge from a computer with the USB cable supplied.

You may use the Music Beany whilst it is charging.



The USB port on the Archos Music Beany is a standard micro USB b/A format, any USB cable with this format can be used to charge your Music Beany. If you use a wall charger make sure that the output does not exceed: 5V / 2A.

Unique solution ID: #1667

Author: Admin FAQ

Last update: 2014-11-04 11:09