

Music Beany

How do I skip music tracks on my Music Beany?

To skip music tracks on your Music Beany simply press the **+** button once to move to the next track, or the **-** button twice to go back to the previous track.

If you press the **-** button once the currently playing track will start again.

Unique solution ID: #1669

Author: Admin FAQ

Last update: 2014-11-04 11:14