

My ARCHOS Hello

How can I change from °C to °F?



In the **Settings tab** , go to General. You can then choose between Celsius (°C) or Fahrenheit (°F).

Unique solution ID: #1459

Author: Admin FAQ

Last update: 2014-10-15 15:04