

# Smart Home Tablet

## Where can I find the photos and videos taken by my accessories or my tablet?

Your photos and videos are available in the folder Pictures > HA. A subfolder is created for each accessory on your system.

If your data are not displayed when you plug your Smart Home Tablet into your computer, simply restart your tablet and plug it in again.

Unique solution ID: #1592

Author: Admin FAQ

Last update: 2014-10-15 16:39