





WiFi

How do I deactivate my WiFi connection?

If you want to deactivate your WiFi connection, you have several solutions:

- In  (or ) **Settings** > **Wireless & networks**, simply slide the WiFi switch to the OFF position.
- In  (or ) **Settings** > **Wireless & networks** > **More...**, you can tick the box **Aeroplane Mode**. Please note, it will deactivate all communication protocols including 3G/4G and Bluetooth®
- You can add the **Battery widget** on your home page from your applications drawer, letting you activate / deactivate WiFi with one press. Please read the [following FAQ](#) for more information about widgets.

Unique solution ID: #1516

Author: Admin FAQ

Last update: 2015-07-06 15:25