



## Battery & Display

### Why doesn't my screen rotate as I am turning my device to landscape ?

Your accelerometer may not be configured correctly. You may be able to reset it from the settings, if so, go to **Settings**  (or ) and recalibrate the accelerometer.

Your Screen rotation option may be deactivated. Check in **Settings**  (or ) >



**Accessibility** to see if Auto-rotate screen is checked.

Unique solution ID: #1527

Author: Admin FAQ

Last update: 2014-11-14 17:03