



Audio & Multimedia

No Sound is coming out of my phone speakers or my headphones, what should I do?

Try this:

- Adjust the audio levels in the **Settings** app  (or ) > **Sound** > Volume of your device
- unplug and replug your headphones then check the audio levels
- Restart the device

If your problem is still unsolved, you may need to [restore the device's system](#).

Unique solution ID: #1553

Author: Admin FAQ

Last update: 2014-11-14 17:04