Troubleshooting

What does it mean when the LED blinks on my accessory?

After a long press on the pairing button (5 seconds):

The LED blinks for 60 seconds: the accessory is in pairing mode and is trying to connect to your Smart Home Tablet.

After a short press on the pairing buton :

- The LED blinks for 10 seconds: your accessory is already paired but is deconnected. It is trying to connect to your Smart Home Tablet.
- The LED blinks 3 times: your accessory is unpaired and disconnected from your Smart Home Tablet
- The LED is ON for 5 seconds: your accessory paired and connected to your Smart Home Tablet
- The LED blinks fast: an over-the-air update is being installed on your accessory.

Unique solution ID: #1632
Author: Admin FAQ
Last update: 2014-10-28 12:18

(c) 2024 ARCHOS <noreply@archos.com> | 2024-03-28 20:19
URL: http://faq.archos.com//index.php?action=artikel&cat=133&id=250&artlang=en