




Others

Why does the maximum resolution for my camera not match the specifications?

The display mode and the camera angle may not be setup correctly given that the maximum resolution is defined by the screen ratio.

To change the resolution, launch the camera app  then select  (or ) in the app. You need to adjust the preview settings to obtain different types of resolution.

Unique solution ID: #1547

Author: Admin FAQ

Last update: 2014-11-14 17:05