

Archives

About ARCHOS 43 Vision



General

When I slide the on ON/OFF button upwards to the "Lock" position, my device shuts off. What's wrong?

The up position on the ON/OFF switch is actually not a screen lock, it is a reset (a few devices had a lock icon incorrectly printed on the back). The screen lock is an automatic system that is set by going to **Settings > System Settings > Key Lock Timer** and then you choose after how many seconds you want the screen to lock automatically. Once the screen is locked, you will notice a padlock icon next to the clock. To unlock it, you just have to slide the green box to the right, and the screen will unlock.

How do I use the screen lock?

The screen lock is an automatic system that is set by going to **Settings > System Settings > Key Lock Timer** and then you choose after how many seconds you want the screen to lock automatically. Once the screen is locked, you will notice a padlock icon next to the clock. To unlock it, you just have to slide the green box to the right, and the screen will unlock.

Unique solution ID: #1271

Author: Admin FAQ

Last update: 2015-05-05 15:46

Page 1 / 1

(c) 2024 ARCHOS <noreply@archos.com> | 2024-04-25 02:55

URL: <http://faq.archos.com//index.php?action=artikel&cat=138&id=93&artlang=en>