

# Archives

## About ARCHOS 2 Vision



### General

#### **Can I delete songs from my ARCHOS?**

You can delete individual songs by selecting Files (fr: fichiers, de:Navigation) from the main screen, and then going to the Music folder and selecting then highlighting the song to delete. Next, press and hold on the volume + button. By selecting Yes, and then pressing the play/pause button, the selected song will be permanently deleted.

### Music

#### **How do I delete a song from my favorites?**

Select favorites and then scroll down to the song you want to remove. Press and hold down on the volume + button. A small menu will appear. Select Remove and press play/pause. This will just delete it from the favorites list, not from the device completely.

#### **How do I set up my Favorites music list?**

To add a song, select 'Music' from the main screen and then select Title. Once you see the song you want to add to your favorites list, press and hold the volume + button. A small menu will appear on the screen. Select "Yes" to add the song to the favorites category.

# Archives

Unique solution ID: #1274

Author: Admin FAQ

Last update: 2015-05-05 15:51