




Weather Station

How can i be warned in case of noise level modification ?

If you want to be informed in case of noise level modification, you must follow this process :

1. On the application homescreen, click the  **Menu** button
2. Select **Alerts**, then press the  button



3. Select the desired settings and press OK.

Weather Station

Edit alert

Noise


is higher than

80db

Cancel

OK

The created alerts are displayed in the Alerts tab.

Use the  button to refresh the incoming alerts.
Unique solution ID: #1782
Author: Admin FAQ 2
Last update: 2015-06-10 15:57