














# Specific by device

## [XS/XS2] What do the keyboard buttons correspond to?

The XS keyboard has many keyboard buttons that allow a quick access.

 Multimedia functions: previous track / play-pause / next track	 Volume setting
 Brightness setting	 Silent mode
 Activate / deactivate your WiFi connection	 Activate / deactivate your Bluetooth® connection
 Notification button	 To delete the selected item
 Back button	 Search button
 Home button	 Recent apps button
 Menu button	

Unique solution ID: #1690

Author: Admin FAQ

Last update: 2014-11-18 10:13