

Archos Fusion Storage

What is Archos Fusion Storage?

ARCHOS Fusion Storage has been developed by ARCHOS to allow you extend your internal storage with a micro-SD card.

Your internal storage is by default separated from your external memory and some applications can only be installed in your internal storage.

For example, if your device has a 8-GB internal storage and you activate ARCHOS Fusion Storage by inserting a 64-GB micro-SD card, the system will inform you that you have a total of 72 GB* to install apps and their related data.

To activate ARCHOS Fusion Storage, see the [following Q/A](#).

* 1 GB = 1 billion bytes. If the card is formatted, the available storage is less.

Unique solution ID: #1804

Author: Admin FAQ

Last update: 2015-10-16 12:05