



# User Interface & Device

## Which options are available in an app?

Apart from the options linked to the app, you can also use two Android™ buttons:

- The **Back** button  lets you go back to previous page / cancel the last action / leave the app. These actions depend on what the developer has set up.
- The **Menu** button  (or the corresponding physical button on your mobile device) can only be used when the developer integrated menu options in its applications. It often corresponds to the app's settings.

The **Home** button lets you go return to the homescreen while leaving the app running in the background. Go to the [following FAQ](#) to close it completely.

According to the app, when you hold your finger on a displayed element, you can open a contextual menu (copy, paste, delete etc...).

Unique solution ID: #1480

Author: Admin FAQ

Last update: 2014-11-14 16:06