

Xenon Series

How to reinitialize my ARCHOS 70 Xenon Color ?



This process is recommended for your device if : it is frozen, it doesn't turn on or you are experiencing a software issue. It will allow you to perform a low level format on your device. Thus all the data will be deleted, you won't be able to retrieve them. We strongly recommend to back them up first. Keep in mind that your device's battery must be charged enough to perform this operation.

Since Android™ 5.0, your device is linked to your Google™ account. If you reset your device from the recovery menu (method 2), you will have to set the same Google™ account you filled in the last wizard. If you reset your device in order to resell it, please use the method 1.

1. If you can have access to the Android™ interface
 - a. Select the Settings app then select Backup & reset.
 - b. Select Factory data reset > "Reset the tablet" and confirm.
2. If you can't access the Android™ interface
 - a. Turn off the device by using ON/OFF.
 - b. While holding Volume +, press ON/OFF until the device turns on.
 - c. On the select boot mode screen, use Volume + to select "Recovery mode" and confirm with Volume - to display the recovery menu.
 - d. Hold down the ON/OFF button again and press the Volume + button once to display the Android system recovery menu when the green robot is displayed.

In the recovery menu, use the volume buttons to navigate and ON/OFF to validate.



If you failed to access to the recovery

Xenon Series

menu, please start again from the beginning.

- a. Select "Wipe data/factory reset" and validate to restore your device to its default settings.
- b. Select "Yes -- delete all user data" and validate to remove all the user data.
- c. Select "Reboot system now" and validate to reboot the device.

Unique solution ID: #1978

Author: Admin FAQ

Last update: 2016-06-02 09:35